

## **SHalloduct Installation Guide.**

Simply tape the two halves together and run through a 94mm twin wall pipe (Rigiduct or similar).

Each section of SHalloduct is 840mm long and can be butt jointed inside the protective sleeve, as per image below:



For joints in ducts use proprietary socket joints available through most merchants.

To turn bends, cut at 45 degrees (mitre) and tape to close or concrete over.