


Groundbreaker® water management system

You are in the fortunate position to have Groundbreaker® as your water control on your property, thus facilitating easy access to water control valve and meter at all times, making meter reading simple – enabling you to manage water supplies efficiently.

Please ensure that you take a few simple steps to ensure your Groundbreaker® unit functions correctly at all times.

Your local water company is responsible for the control valve and water meter inside Groundbreaker® but as householder it is YOUR responsibility to ensure that the door is closed at all times when meter reading is not required.

Follow these simple steps to ensure total product performance, if in any doubt, please contact your local water company, details of which will be found on your water bills or yellow pages.



Always use plastic key provided



Toggle latches

Please note: Door is designed to fall OPEN if not correctly closed (failsafe)

Inner workings:




Water Meter Control Valve

Outlet pipe (option 1)

Outlet pipe (option 2)

Incoming water service pipe



Responsibility of pipes – please contact your local water company if you need clarification