

LoFlo[®]

INLINE WATER FLOW REGULATOR

by Groundbreaker Installation guide

Locate the main water supply stop tap – this can usually be found under the kitchen sink and located before the water meter if the meter is internal.

Before isolating your water supply ensure that all water using appliances are switched off.

Turn off mains water supply and drain down residual water left in the pipe.

Scenario A - connecting onto existing meter

- Disconnect the 3/4" nut from the meter tail – ensure that this is on the outlet of the meter
- Fit the LoFlo onto the 3/4" meter tail
- Remove the existing 3/4" nut from the pipe and connect the LoFlo to the existing pipe using a 22mm coupler. For 15mm supply pipes fit a reducer.

Scenario B - connecting to the stop tap

- Cut into the pipework after the stop tap
- Fit a 15mm x 3/4" or 22mm x 3/4" male tail and connect the LoFlo to the 3/4" tail
- Connect the LoFlo onto the existing pipe using a 22mm coupler. For 15mm supply pipes fit a reducer.

Turn on the water supply and test for any leaks.

We recommend that you use an approved plumber to carry out the work – please go to www.WaterSafe.org.uk to find your nearest approved plumber.

